

INSTALLATION INSTRUCTIONS


(ILLUSTRATIONS ARE FOR GUIDANCE PURPOSES ONLY, ACTUAL PRODUCT MAY DIFFER FROM THE IMAGES SHOWN) PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.





(2) These instructions should be used in conjunction with the installation guidelines included.




3









⚠ WARNING

- (1) This unit must be fitted by a competent and qualified electrician.
- (2) Install in accordance with current IEE Wiring regulations and current Building Regulations.
- (3) To prevent electrocution switch off at mains supply before installing or maintaining this fitting and ensure the power cannot be restored without your knowledge.
- (4) Always use the correct type and wattage bulb. Never exceed the wattage stated.
- (5) When changing a bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully and responsibly.
- (6) Please ensure there is a minimum 20mm ventilation space above the lamp.
- (7) Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist.
- (8) Check with your local authority or retailer for recycling advice.
- (9) The fixture/lamp should NOT be covered with insulating material.
- (10) If using Halogen lamps they should be a minimum distance of 30cm from the illuminated surface.



INSTALLATION

- (1) Switch off power.
- (2) Cut a hole in the ceiling 60mm in diameter.
- (3) Attach the lampholder/wire assembly to the side of the fitting by sliding the middle fork through the centre of the spring.
- (4) Push the securing side back and slide the crystal fascia over the retaining ring.
- (5) Connect the lampholder/wire assembly to the power supply via connector block (*This item is a double insulated product and does not require an earth*).
- (6) Push the securing side springs back and insert the fitting into the hole.
- (7) Put the lamp into the lampholder and secure using the spring.

Dante - IL30833CH /34CH /35CH / 35FG/ 36CH /37CH



PAGE 2 of 2













ISSUE: 20160119




















IL30834CH (Square)



IL30835CH / IL30836FC (Round)



IL30836CH (Round)



IL30837CH (Square)

Dante - IL30833CH /34CH /35CH / 35FG/ 36CH /37CH

